

Installation Instructions

2X15L

2X18L

2X20L

1

Take out the buckets before installation

2

Center the metal frame in the cabiner correctly

3

fix the metal frame with 4 metal brackets and screws

Short Screws
Long Screws

4

2X15L

2X18L

2X20L

Refer to the bin volume and find out the corresponding door mountde sizes

5

1)measure internal width of cabiner and make on the door panel
2)Door mounted fittings position =(a-320)/2 and also refer to step 4 (height distance info.)

6

Assembly the bin frame to door panel with screws

7

Adjust horizontal Adjust vertical Adjust forward/backward Lock adjustments

8

Insert Bins&cover